



Einhell

EXPERT

POWER X-CHANGE

Cordless Surface Brush

PICOBELLA 18/215

Item No.: 3424200

Ident No.: 21043

Bar Code: 4006825645767

The Einhell PICOBELLA 18/215 cordless surface brush is a multifunctional supporter to clean stone, wood, artificial turf and edges. As a member of the Power X-Change battery system, every system battery can be used. The PICOBELLA 18/215 has an integrated garden hose connection incl. water control valve, an all-round dirt guard hood, extra-wide rotating brush rollers, flexible forward/reverse operation and infinitely adjustable speed control. The brushes can be changed at the press of a button. A special side brush is perfectly suited for perimeter work. The additional handle has an integrated garden hose guide. The product is supplied complete with a MEDIUM brush for cleaning stone. This product comes without battery or charger.

Features & Benefits

- Member of the Power X-Change family
- Multifunctional: Cleaning of stone, wood, artificial turf & edges
- Only one working step thanks integrated garden hose connection
- Economical use of water by manually regulation possibility
- Brush change without tools at the push of a button
- Special side brush for cleaning right to the wall and into edges
- Extra wide rotating brush for fast cleaning results
- Max. results thanks flexible forward-/reverse running of brush
- Height adjustable aluminium tube enables back-friendly work
- Steplessly adjustable speed control for additional flexibility
- Surrounding protection cover as perfect splash guard
- Additional handle with integrated garden hose routing
- Brush MEDIUM for stone cleaning included in delivery
- Ergonomic main handle with softgrip
- Supplied without battery and charger (available separately)




Technical Data

- Voltage 18 V
- Rotation speed 800 - 1400 min⁻¹
- Diameter of brush 115 mm
- Working width (brush MEDIUM) 215 mm

Logistic Data

- Product weight (kg) 4.1
- Gross weight (kg) 5.6
- Dimensions single packaging 1150 x 250 x 215 mm
- Pieces per export carton 2 Pieces
- Gross weight of export carton 12.4 kg
- Dimensions export carton 1170 x 270 x 320 mm
- Container quantity (20"/40"/40"HC) 572 | 1144 | 1304



Available as special accessories



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



Brush SOFT (wood, artif. turf)
Surface Brush Accessory
Item No.: 3424121
Bar Code: 4006825646252
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



PXC Akku-Wandhalterung
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



side brush ULTRA (stone)
Surface Brush Accessory
Item No.: 3424126
Bar Code: 4006825660845
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



Brush MEDIUM (Stone)
Surface Brush Accessory
Item No.: 3424120
Bar Code: 4006825646245
Einhell Accessory



Brush ULTRA (Stone)
Surface Brush Accessory
Item No.: 3424122
Bar Code: 4006825646269
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory

Battery-Running-Times

One Battery for All	 cleaning ¹ (min.)	 cleaning ² (min.)
1.5 Ah	25	8
2.0 Ah	30	10
2.5 Ah	34	12
3.0 Ah	46	17
4.0 Ah	55	20
5.2 Ah	70	25
6.0 Ah	90	29
8.0 Ah	110	40

Test setup:

1) nylon - Min. electronic speed

2) nylon - Max. electronic speed