



# Einhell

# EXPERT

## POWER X-CHANGE

**Cordless Sweeper**

**TE-FS 18 Li-Solo**

**Item No.: 2352050**

Ident No.: 21013

Bar Code: 4006825675184

The Einhell TE-FS 18 Li-Silo wireless broom is the ideal helper for cleaning tasks. As a member of the Power X-Change family, the broom can be combined with all batteries and charging devices across the system. Its flexible swivel joint makes it easy to clean. Rubberized wheels help with maneuvering. Its compact and lightweight design enables fatigue-free sweeping with the telescopic handle. The 250 mm wide cleaning brush removes dry dirt from all hard floors and carpets. This ends up in a 400 ml collecting container. The TE-FS 18 Li wireless broom comes with 3x side brushes and 1x cleaning tool. Delivery does not include battery or charging device (sold separately).

## Features & Benefits

- Part of the Power X-Change family, 1 x 18 V battery required
- Flexible swivel joint enables cleaning of bottlenecks
- Compact, lightweight design for fatigue-free sweeping
- Interchangeable, easy-to-clean cleaning roller
- Cleaning lip for sweeping hard floors & carpets
- Self-standing function for easy storage
- Telescopic handle for ergonomic sweeping
- Easy cleaning of the removable collection container
- LED light for cleaning in dark areas
- Rubberised wheels for easy manoeuvring
- Including 3x side brush for cleaning near the edge on hard floors
- Including 1x cleaning tool for removing hair from the brush
- Delivered without battery or charging device (available separately)



## Technical Data

- Working width 25 cm
- Dust container capacity 0.4 L
- Self-standing function yes
- Base height 10.8 cm



## Logistic Data

- Product weight (kg) 2
- Gross weight (kg) 3.6
- Dimensions single packaging 300 x 260 x 950 mm
- Pieces per export carton 4 Pieces
- Gross weight of export carton 15.5 kg
- Dimensions export carton 660 x 330 x 600 mm
- Container quantity (20"/40"/40"HC) 864 | 1920 | 2084



## Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery  
Item No.: 4511502  
Bar Code: 4006825644210



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



4,0 Ah Power X-Change Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Fastcharger 4A Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



5,2Ah & 4A Fastcharger  
PXC-Starter-Kit  
Item No.: 4512114  
Bar Code: 4006825656787  
Einhell Accessory



PXC Battery Mounting Gadget  
PXC-Battery Accessory  
Item No.: 4514155  
Bar Code: 4006825658774  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB A1 Battery  
Item No.: 4511489  
Bar Code: 4006825638578



3,0 Ah Power X-Change Plus Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



5,2 Ah Power X-Change Plus Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



2,0 Ah Power X-Change Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory